

## **EQUIPMENT MAINTENANCE CHART**

## **AER 1000 MICROAIRE DAF® SYSTEM**

100	T ==0.01	54111/	14/55/41/4		2 2 2 2 2 1 7 1 7	6 1 4 <b>6</b> 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	
LOC	TASK	DAILY	WEEKLY	MONTHLY	3 MONTHS	6 MONTHS	YEARLY
1	CHECK THAT AERATION SYSTEM PRESSURES ARE AS SPECIFIED (100- 110 PSI AT HEADER 15-25 PSI LESS AT SAT TANK)	✓	-	-	-	-	-
2	CHECK THAT AIR SUPPLY PRESSURE AT THE INLET OF THE FILTER/REGULATOR IS AT LEAST 20 PSI HIGHER THAN PRESSURE IN THE HEADER	<b>✓</b>	-	-	-	-	-
3	CHECK THAT AIR FLOW METER INDICATOR BALL IS IN THE "GREEN" RANGE	✓	-	-	-	-	-
4	CHECK THAT VENT LINE IS EXPELLING AIR AND WATER (APRROX 50%/50%)	<b>√</b>	-	1	1	1	ı
5	DRAIN CONDENSATE FROM AIR FILTER/REGULATOR	✓	✓	-	-	✓	-
6	CHANGE RECIRCULATION PUMP BEARING LUBRICANT (REFER TO MANUFACTURER LITERATURE IN MANUAL)	-	-	-	-	<b>√</b>	-
7	LUBE BEARINGS IN ELECTRIC MOTOR FOR RECYCLE PUMP (REFER TO MANUFACTURER LITERATURE IN MANUAL)	-	<b>√</b>	-	-	-	-







